

# Gebruikershandleiding AXIWI AT-350

## 6 personen duplex communicatie

Om AXIWI te kunnen gebruiken dient u één unit in te stellen als 'Master'. De andere units kunt u instellen als 'Submaster' of 'Follower', afhankelijk van of u continu of incidenteel met elkaar wil praten. In de 'Submaster' modus is de spreekfunctie continu geactiveerd. In de 'Follower' modus kunt u de spreekfunctie handmatig activeren en deactiveren.

Voor het instellen van het AXIWI communicatiesysteem dient u de volgende stappen volgen.

### **Voordat u begint, plug eerst de headset in de AXIWI.**

#### **Instellen als Master**

- 1.Druk de volumeknop  $\blacktriangle$  in.
- 2.Vervolgens drukt u de 'aan/uit' knop in (minimaal 2 seconden), terwijl de volumeknop  $\blacktriangle$  nog steeds ingedrukt is.
- 3.Het apparaat is ingeschakeld als 'Master'; de letter 'M' verschijnt links boven in het display.

#### **Instellen als Submaster**

- 1.Druk de volumeknop  $\blacktriangledown$  in.
- 2.Vervolgens drukt u de 'aan/uit' knop in (minimaal 2 seconden), terwijl de volumeknop nog steeds ingedrukt is.
- 3.Het apparaat is ingeschakeld als 'Submaster'; de spreekfunctie is nu continu geactiveerd.

#### **Instellen als Follower**

- 1.Druk de 'aan/uit' knop minimaal 2 seconden in. De AXIWI is nu ingesteld als Follower.
- 2.Met de spreekfunctie toets aan de voorzijde kan de spreekfunctie geactiveerd en gedeactiveerd worden. Druk de toets kort in om de spreekfunctie te activeren. Druk de toets nogmaals kort in om de spreekfunctie te deactiveren.
- 3.Wanneer de spreekfunctie geactiveerd is, zal een microfoon in het display verschijnen.

#### **Veranderen van kanaal**

Druk de M-knop kort in. U zult zien dat het kanaal gaat knipperen, u kunt met  $\blacktriangledown$  of  $\blacktriangle$  het kanaal kiezen. U bevestigt het kanaal met de M-knop.



# User manual AXIWI AT-350

6 persons two-way (duplex) communication

With the AXIWI communication system, you have to setup 1 unit as a ‘Master’. The other units have to be set up as a ‘Submaster’ or a ‘Follower’, depending if you want to be able to talk continuously or incidentally. In the ‘Submaster’ mode your speaking function is always activated. In the ‘Follower’ mode you have to manually activate and deactivate your speaking function.

In order to set up the AXIWI communication system, you have to make the following installation steps.

## Before you start, first plug in the headsets.

### Set up as Master

- 1.Push and hold the volume up ▲ button.
- 2.Then push the ‘on/off’ button (At least 2 seconds) while pushing the volume button ▲ at the same time.
- 3.The AXIWI unit is set up in the ‘Master’ mode; the letter ‘M’ appears at the left top of the display.

### Set up as Submaster

- 1.Push and hold the volume ▼ button.
- 2.Then push the ‘on/off’ button (At least 2 seconds) while pushing the volume button ▼ at the same time.
- 3.The AXIWI unit is set up as ‘Submaster’; the speaking function of the AXIWI is continuously activated.

### Set up as Follower

- 1.Push the ‘on /off’ button for at least 2 seconds. The AXIWI is set up as Follower.
- 2.With the speaking button on the front, the speaking function can be activated and deactivated. Press the speaking button briefly to activate (and again) to deactivate the speaking function.
- 3.When the speaking function is activated a microphone will appear in the display.

### Change the channel

Press the M-button briefly. The channel will blink. With the up ▲ or ▼ down button you can change the channel. You confirm the channel with the M-button.

